







WB 486 CRB

2018




2 WB486CRB Deck Assembly




Order	Part number	Name_English	Quantity
1	48R0101030/21	Chassis	1
2	48R0300035/21	Engine Washer	1
3	0101008040	Bolt	4
4	0303008000	Big Washer	4
5	0301008000	Spacer	1
6	0202008000	Lock Nut	5
7	48R0107021/21	Bush	2
8	48R0117014/22	Adjustment Lever	1
9	46R0137010	Adjustment Lever Grip	1
10	48R0117015/22	Adjustment Lever Hook	1
11	0301010000	Flat Washer	9
12	0202001000	Lock Nut	8
13	0201008000	Nut	2
14	0101008015	Bolt	4
15	0401008000	Spring Washer	4
16	0101008080	Bolt	2
17	5320333010	Check Ring	1
18	46R0138010	Plastic Grip	1
19	48R0138010	Plastic Grip	1
20	0102008035	Hex Flange Bolt	2
21	48R0131010/21	Lever Axle Weldment	1
22	0102008025	Flange Bolt	2
23	0102008025	Flange Bolt	2
24	0202006000	Lock Nut	2
25	48R0129010/02	Rear Cover Axle	1
26	48R0130010	Rear Cover	1
27	48R0201020/02	Front Axle	1
28	48R0201030	Spacer	2
29	48R0201040	Spacer1	2
30	48R0204020/21	Connecting Rod	2
31	48R0205010/02	Connecting Rod Inner Partition	2
32	5310213010	Bearing	8
33	48R0208030/02	Rear Axle	2
34	5310210010/02	Axle Washer	2
35	5310211010/02	Spacer	4
36	48R0210011	Wheel 8"	4
37	48R0210012	Wheel Cap	4
38	0301016000	Flat Washer	2
39	0202016000	Lock Nut	2
40	UCF204	Bearing With Holder	2
41	0101010030	Bolt	4
42	0101010025	Bolt	4
43	48R0312010	Axle Head Sleeve	1
44	48R0105020/21	Chassis Protection Plate	1
45	0401010000	Spring Washer	8

3 WB486CRB Blade Component




Order	Part number	Name_English	Quantity
1			1
2	48R0301020S/22	Rotor Assembly	1
3	48R0304010/04	Blade Pivot	4
4	46R0306010/04	Blade	28
5	48R0306010	Blade Bush II	48
6	48R0307010	Blade Bush I	14
7	48R0308010	Nylon Spacer	12
8	0701004025	Spring Pin	8

4 WB486CRB Handlebar





Order	Part number	Name_English	Quantity
1	40R0501013/02	Upper Handle Limit Plate Partition	2
2	40R0501012/22	Upper Handle Limit Plate	1
3	0102006035	Hex Flange Bolt	2
4	40R0501014	Torsional Spring	1
5	0301010000	Flat Washer	2
6	0202001000	Lock nut	2
7	0202006000	Lock nut	2
8	KG/WB384RB	Switch	1
9	0113004012	Screw Bolt	2
10	WB/KG04	Lower Chassis	1
11	WB/KG01	Rubber Ring	1
12	WB/KG03	Upper Chassis	1
13	WB/KG02	Rubber ring	1
14	40E0109000	Cable Pressing Bracket	1
15	48R0401030/22	Upper Handle	1
16	0104006045	Cross Head Screw	1
17	0301006000	Spacer	3
18	48R0404020/02	Cluth Cable Bracket	1
19	48R0405030/22	Clutch handle assembly	1
20	48R0409030	Clutch Cable	1
21	48R0410010	Tensional Spring	1
22	5310510010	Screw - 8x45	2
23	4510510010	Washer	2
24	4820541010	Handle Wheel	2
25	48R0416010/22	Lower Handle	1
26	0102010020	Flange Bolt	4
27	48R0414010/02	Cable Bracket	1
28	40R0502020/02	Switch Bracket	1
29	5320517010	Clip	1

5 WB486CRB



Order	Part number	Name_English	Quantity
1	4LXA782	Belt	2
2	1101006020	Key	1
3	40R0134010/04	Big Pulley	1
4	0303008000	Big Washer	2
5	0101008015	Bolt	2
6	0401008000	Spring Washer	2
7	1101005030	Key	1
8	40R0119111/02	Engine Pulley Bush	1
9	40R0133010/04	Engine Pulley	1
10	0101008080	Bolt	2
11	48R0116010S/21	Engine Plate	1
12	5340113020	Hex Bolt	4
13	48R0107021/21	Bush Washer	2
14	0201008000	Nut	2
15	0301008000	Flat Washer	12
16	48R0136000S/21	Belt Shield	1
17	0301008000	Spacer	4
18	0207008000	Cap Nut	4

6 WB486CRB Tension Part



Order	Part number	Name_English	Quantity
1	48R0113010	Nylon Bush	2
2	48R0111010/02	Rotating Plate	1
3	03O1012000	Spacer	1
4	1001012000	Check Ring	1
5	0103010050	Inner Hex Screw	1
6	0901026000	Check Ring For Hole	1
7	6000ZZ	Ball bearing	2
8	51A0126010/02	Bush I	1
9	51A0125010/02	Tension Pulley	1
10	48R0115010/02	Partition	1
11	0301010000	Spacer	1
12	0202001000	Lock Nut	1
13	40R0107023	Tensional Pulley Spring	1